

Mastermodule 2 3 0 V

DE-102111 SERVOSTAR™ 403M-NA CANopen 3 9
DE-102117 SERVOSTAR™ 406M-NA* CANopen 6 12
DE-102113 SERVOSTAR™ 403M-PB PROFIBUS 3 9
DE-102119 SERVOSTAR™ 406M-PB* PROFIBUS 6 12
DE-102115 SERVOSTAR™ 403M-SE SERCOS 3 9
DE-102121 SERVOSTAR™ 406M-SE* SERCOS 6 12
DE-200740 SERVOSTAR™ 403M-EC ETHERCAT 3 9
DE-200741 SERVOSTAR™ 406M-EC* ETHERCAT 6 12

Mastermodule 4 0 0 V

DE-102111 SERVOSTAR™ 403M-NA CANopen 3
DE-102117 SERVOSTAR™ 406M-NA* CANopen 6
DE-102113 SERVOSTAR™ 403M-PB PROFIBUS 3 9
DE-102119 SERVOSTAR™ 406M-PB* PROFIBUS 6 12
DE-102115 SERVOSTAR™ 403M-SE SERCOS 3 9
DE-102121 SERVOSTAR™ 406M-SE* SERCOS 6
DE-200740 SERVOSTAR™ 403M-EC ETHERCAT 3 9

Mastermodule 4 0 0 V

DE-102832 SERVOSTAR™ 443M-NA CANopen 3 9
DE-102833 SERVOSTAR™ 446M-NA* CANopen 6 12
DE-102834 SERVOSTAR™ 443M-PB PROFIBUS 3 9
DE-102835 SERVOSTAR™ 446M-PB* PROFIBUS 6 12
DE-102976 SERVOSTAR™ 443M-SE SERCOS 3 9
DE-102977 SERVOSTAR™ 446M-SE* SERCOS 6 12
DE-200742 SERVOSTAR™ 443M-EC ETHERCAT 3 9
DE-200684 SERVOSTAR™ 446M-EC* ETHERCAT 6 12

Achsmodule 2 3 0 / 4 0 0 V

DE-102112 SERVOSTAR™ 403A-NA CANopen 3 9
DE-102118 SERVOSTAR™ 406A-NA* CANopen 6 12
DE-102114 SERVOSTAR™ 403A-PB PROFIBUS 3 9
DE-102120 SERVOSTAR™ 406A-PB* PROFIBUS 6 12
DE-102116 SERVOSTAR™ 403A-SE SERCOS 3 9
DE-102122 SERVOSTAR™ 406A-SE* SERCOS 6 12
DE-200686 SERVOSTAR™ 403A-EC ETHERCAT 3 9
DE-200685 SERVOSTAR™ 406A-EC* ETHERCAT 6 12